

User Manual

GL16 dp 1000



Version 3.3

18.05.2020

SEEBURG
acoustic line

1 Contents

1	Contents	2
2	Foreword.....	3
3	Safety instructions.....	4
4	Connectors/Indicators.....	6
4.1	Connection Panel	6
4.2	Connectors	7
4.3	Controls.....	8
4.4	Status indication.....	8
5	Operation	9
5.1	Starting up.....	9
5.2	Selecting a bank	9
5.3	Setting level	10
5.4	Recalling presets	10
5.4.1	Preset Bank 1 – Compatibility Mode	10
5.4.2	Preset Bank 2 – Default Settings.....	11
5.5	Reprogramming of dp-speakers with preset audio files.....	12
5.6	Locking the buttons	12
6	Technical specifications	13
7	Declaration of conformity	14

2 Foreword

The GL16 dp 1000 is a high-performance line source for defined speech- and music-reproduction in acoustically difficult rooms, even over a long distance. It features digital amplifier electronics with 2x 500 Watt power @ 4 ohms (AES) and a DSP controller. The GL16 dp 1000 is available in the i version (7° vertical coverage) and in the c version (30° vertical coverage). Various pre-configured presets and volume settings are available for selection.

The integrated DSP controller is based on the same operating principle as the stand-alone controllers HDLM 8 and DSP 2.6. A mere 0.8 ms latency (from analogue input to output) is achieved through the use of a 96 kHz sample rate. The excellent signal to noise ratio is a further feature of the DSP controller. Electronic simulation of a transformer balanced input provides additional protection against hum and buzz caused for example by external interference. High grade electronic components from the industrial sector and first-class circuit design result in a robust device with excellent audio characteristics and minimize disruptive noise.

The default state of the integrated DSP controller is the standard configuration as described in this manual. Custom presets can be installed by the user, but must be programmed with the LPI (Loudspeaker Programming Interface) by the manufacturer. The preset file is a custom audio file which is simply played into the audio input of the controller. In this manner, individual configurations can be created, for instance to accommodate the specific requirements of an installation project. Furthermore, should you ever be unsure as to the integrity of the DSP configuration of your controller, you can obtain a fresh default file from SEEBURG acoustic line and re-install the original factory presets yourself. Efficient and intelligent limiter functions provide optimal protection without sacrificing any of the potential of the system.

If you would like further information about SEEBURG acoustic line products, or have any comments or suggestions regarding this handbook or the product, you can contact us here:

SEEBURG acoustic line Produktions- und Vertriebsgesellschaft mbH

Auweg 32

89231 Senden

07307 / 9700 – 0

www.seeburg.com

info@seeburg.net

3 Safety instructions



Acoustic

Even a low input level can result in a sound pressure level at the loudspeaker which can be damaging to your hearing. Do not remain in close proximity to the loudspeaker when it is being operated. Use hearing protection. Observe all relevant Health and Safety and Environmental Protection regulations.



Mechanical

Movable parts and falling objects during installation and de-rigging can cause serious injury. Observe at all times all relevant Health and Safety regulations and regulations on the installation and operation of PA systems.



Magnetic und electrical

Loudspeakers generate a magnetic field even without a source of power connected. This can damage or destroy magnetic storage devices. The PowerCon loop-through connector is under power when the device is in operation. Observe all relevant safety regulations at all times.



General safety precautions

The installation and de-rigging of this equipment should only be carried out by appropriately qualified and experienced personnel, and according to all relevant safety regulations. Find out about the applicable regulations in the country you work in and comply with the respective regulations.

Do not operate the loudspeaker if you have any doubts about the safety of doing so, or if the loudspeaker shows any signs of faulty operation. There are no user serviceable parts inside the device. For repairs, contact your dealer or a qualified service technician.

The loudspeaker is a class 1 device requiring a 230 V / 50 Hz power connection with earth contact.


If the loudspeaker is connected to a power source in which the voltage is too high, a protective mechanism is triggered which reliably safeguards the amplifier module and DSP. Once triggered, the protection must be renewed by a qualified service technician.

Never open the housing. There are no user serviceable parts inside. Do not expose the loudspeaker to rain, and avoid operating in environments below -5°C or above 40°C . Be aware of the possibility of condensation forming inside the housing due to rapid changes in temperature. Allow the loudspeaker to adjust to ambient temperature before operation. Leave the device switched on if operating in unfavorable conditions.

To prevent overheating, do not operate the loudspeaker in the direct vicinity of strong heat sources, and avoid direct sunlight. After long periods of operation, the loudspeaker, particularly metallic components such as the pole mount and the connector panel, can reach temperatures exceeding 40°C .

4 Connectors/Indicators

4.1 Connection Panel



4.2 Connectors

XLR connectors (1)

The GL16 dp 1000 should be connected with a standard symmetrically wired XLR cable. To connect the input signal to further devices, use the male XLR Loop thru connector. To obtain full power performance from the system, the signal source should be able to provide a minimum of 6 dBu distortion free output voltage.

PowerCon blue (2)

Power supply input voltage 110-230 VAC. This connector provides the function of an on-off switch. After powering on (turn the connector to the right until it locks), the systems starts up and is ready for use after approximately 3 seconds. Avoid repeatedly switching the system on and off, particularly when it is operating.


PowerCon grey (3)

110-230 VAC loop-through connector. This connector is to be used when multiple active loudspeakers are to be provided with power from one source. Please observe carefully the maximum power capacity of the power source.



The nominal power consumption of the GL16 dp 1000 under full power is 0.85 A (measured with pink noise, Crest Factor 8). Transient peaks can, however, cause much higher momentary power drain. Observe carefully the nominal power consumption when connecting the loudspeaker(s) to the power source, and observe carefully the cut-off current of the safety circuit breakers. We recommend using the loudspeaker on power circuits with circuit breakers with C characteristic.

4.3 Controls




Mode button:

Switch between the modes Status / Level and Presets.

Set button:

Set various values and Mute on/off.

4.4 Status indication



Mute LED:

Lights red when the system is muted (press the Set button in Status Mode), or in technically critical conditions.

Limit LED:

Lights yellow when the limiter is limiting one or more amplifier channels.

Signal LED:

Lights green when a signal of more than -20 dBu is present. The LED still lights up when the system is muted.

Power LED:


Lights when the system is powered up.

5 Operation

5.1 Starting up

When the system is switched on, it retains the settings from the previous usage. This also applies to the Bank selection. The system is then in the Status Mode. If the red Mute LED is lit as a result of the previous setting, no signal will be passed. Pressing the Set button once will un-mute the system. The Mute LED will go off, and signal will be passed.

5.2 Selecting a bank



The loudspeaker presets are stored in the DSP controller in up to 3 banks. To change banks, press and hold the Mode button whilst the loudspeaker is switched on.


1. Press and hold the Mode button.
2. Connect the power cable (PowerCon blue).
3. Corresponding LEDs blink to indicate the chosen bank.
4. Release the Mode button.

When the power cable is connected, the level and/or preset LED lamps blink to indicate which bank is selected. The level LED blinks to indicate the first bank, the preset LED for the second. The third bank is indicated by both LEDs blinking.

If only one bank is programmed, there is no possibility to switch the bank.

Bank 1 – Compatibility Mode	Bank 2 – Default Settings	Bank 3
Flat	Flat	-
-Low	-Low	-
--Low	--Low	-
Switchable HP Mode	Switchable HP Mode	-

5.3 Setting level



Pressing the Mode button once selects the Level Mode, in which you can adjust the output volume in 3 dB steps. There are four settings available: +3 dB, 0 dB (standard), -3 dB and -6 dB. The setting is done by pressing the Set button. The Level LED lights to indicate which mode is activated. The four vertically aligned LEDs (lit green in this mode) indicate which setting is selected.

5.4 Recalling presets


Pressing the Mode button twice selects the Preset Mode. Three different presets with an each switchable high pass mode are available in each bank for selection via the Set button. The four vertically aligned LEDs indicate the current selection. The high pass mode is activated in the preset when the bottom of the four vertical LEDs lights up.



Increasing the length of the line source of the GL system results in a level addition in the low-mid range and stronger bundling compared to a single system. The presets "Flat", "-Low" and "--Low" therefore can be selected to adjust the frequency response, depending on the length of the line source and the throw distance. The choice of the preset should also be made according to room size and listening habits.

5.4.1 Preset Bank 1 – Compatibility Mode

This bank contains a Compatibility Mode. The presets are acoustically compatible with GL16 dp 1000 systems that are **not** fitted with the *DPLM*-DSP controller.



Flat:
Preset for single application without any subwoofer.

-Low:
Preset with a level reduction of the low-mid range.
(e.g. for 2 GL systems as one line source)


--Low:
Preset with more level reduction of the low-mid range.
(e.g. for 3 GL systems or more as one line source)

HP Mode:

HP Mode should be activated when using additional subwoofers (e.g. G Sub 1501 dp). The high pass function works regardless of the choice of three possible presets. If this mode is switched on, the GL16 dp 1000 and the GL system connected to the parallel output are operating in high pass mode.

5.4.2 Preset Bank 2 – Default Settings

This bank contains the recommended settings for GL16 dp 1000 systems fitted with the *DPLM*-DSP-controller.

**Flat:**

Preset for single application without any subwoofer.

-Low:

Preset with a level reduction of the low-mid range.

(e.g. for 2 GL systems as one line source)

--Low:

Preset with more level reduction of the low-mid range.

(e.g. for 3 GL systems or more as one line source)

HP Mode:

HP Mode should be activated when using additional subwoofers (e.g. G Sub 1501 dp). The high pass function works regardless of the choice of three possible presets. If this mode is switched on, the GL16 dp 1000 and the GL system connected to the parallel output are operating in high pass mode.

5.5 Reprogramming of dp-speakers with preset audio files

By default, the built-in DSP controller is in a default configuration state that conforms to the description in the User Manual. The installation of special presets on the DSP controller can be done by the user himself, since only a special preset audio file must be loaded. The programming of these audio files via the LPI (Loudspeaker Programming Interface) can only be done by the manufacturer.


The preset is getting installed on the DSP by playing the preset audio file in the XLR input. This can be done in different ways (MP3 player, smart phone, PC, CD player, ...). Installation via PC is done as follows:

1. Use a mini-jack-XLR (stereo) cable to connect the headphone output to the XLR input of the self-powered box. Use only one of the XLR connectors.
2. Mute the box by pressing the Set button in Status Mode. The Mute LED lights up. The DSP controller can only receive data in the muted state.
3. Make sure your computer's volume is set to 100%.
4. Load the ".wav" file received from SEEBURG acoustic line into a music player.
5. Press the play button.
6. After a successful programming operation, the Mute LED turns off.



It is very important to ensure that the preset audio file is played in single mode. Other music files in the playlist or on the data storage medium will otherwise be played at full volume.

5.6 Locking the buttons



Press and hold the Set and Mode buttons simultaneously for more than 3 seconds to lock the controls of the system. Repeat the action to unlock the system.

6 Technical specifications

Speaker Components	4 x 6,5" Nd / 16 x 1" Nd Tweeter
Description	Two-Way Line Array System
Amp Power	2 x 500 W AES / 110-230 V biamped
Rated Current	0,85 A @ 230 V
SPL (Peak @ 1m)	> 130 dB
Max. Input Signal	25 dBu
DSP	HDLM FPGA Processing 32 bit floating point
AD / DA	24 bit / 96 kHz
Latency	0,8 ms (analog in to analog out)
Usable Range (-6dB)	80 Hz - 20 kHz
Tuning Frequency (excursion minimum)	90 Hz
X - Overpoint (acoustical)	depends on preset
Coverage (horizontal / vertical)	100° x 7° - i-version 100° x 23° - c-version
Mechanical Splay Angle	0° (i-version) 16° (c-version)
Connectors	Neutrik XLR in/out Neutrik PowerCon in/out
Handles	1 x
Rigging (flying points)	12 x M10 Integrated Flying Hardware
Weight	17,0 kg
Size (height x width x depth)	70,8 x 19,0 x 24,5 cm (i-version) 72,0 x 19,0 x 26,2 (24,5) cm (c-version)
Order No.	00500/2x500W (i-version) 00501/2x500W (c-version)

The technical data sheet and further information about possible applications for the system and available accessories can be downloaded at the following Internet address:

http://www.seeburg.net/download_getfile.php?file=downloads/06-Datenblaetter/GL-Serie/GL16_Datenblatt_dt.pdf



This manual applies only to systems fitted with the *DPLM*-DSP Controller.

The version fitted with the *DPLM*-DSP Controller can be identified by the control panel located above the XLR connectors.

7 Declaration of conformity

EG Declaration of conformity

This product

GL16 dp 1000

confirms to the following EU guidelines, including any additions:

- ✓ 2006/95/EG, Low Voltage
- ✓ 2004/108/EG, Electromagnetic Compatibility
- ✓ (Locations: Appendix 1, Paragraph 1, a and b)


The following standards have been applied:

- ✓ DIN EN 60065
- ✓ DIN EN 55103-1:1996, classes E1 to E4
- ✓ DIN EN 55103-2:1996, classes E1 to E4

Declared by: Winfried Seeburg, SEEBURG acoustic line GmbH

Place and date: Senden, 01.01.2010

Legally binding sign: _____



The attachments constitute part of this declaration. This declaration certifies conformity with the listed guidelines, but does not guarantee any product characteristics. The safety precautions listed in the product documentation must be observed.

SEEBURG acoustic line Produktions- und Vertriebsgesellschaft mbH

Auweg 32

89231 Senden

07307 / 9700 – 0

Benutzerhandbuch / User Manual

Irrtum bei Beschreibung
sowie technische
Änderungen vorbehalten.

Alle SEEBURG acoustic line
Produkte sind nur für den
gewerblichen Einsatz bestimmt.

All specifications are
current at the time of publishing
but are subject to change.

SEEBURG acoustic line
Produktions- und Vertriebs GmbH

Auweg 32
D-089250 Senden-Freudenegg

Fon: +49 (0)7307 97 00- 0
Fax: +49 (0)7307 97 00- 29

www.seeburg.com
info@seeburg.net